

# usb edition

quick start guide

temperature @ lert.

## 1 install the software

Download the latest USB software from [temperaturealert.com/support](http://temperaturealert.com/support) or insert the included software CD into your PC's CD-ROM drive. The installation program will automatically start. If it does not, browse the CD and double click on setup.exe. Follow the prompts to complete the software installation wizard.

## 2 connect the hardware

Connect the Temperature@lert USB sensor to an available USB port on your computer. If possible, use a USB extension cable to minimize heating from the computer. Windows will automatically detect and install the new hardware.

## 3 configure the software

From the start menu, click on All Programs, then the Temperature@lert folder, and finally on the Temperature@lert program. Click the Settings tab. The sensor should automatically be detected on an available COM port. If no sensor is listed, click rescan. Enter your alarm thresholds and SMTP settings. Click save and apply to begin monitoring temperature.

To get help and review the complete user guide  
visit [www.temperaturealert.com/support](http://www.temperaturealert.com/support)